




Principle

The SUP-TreeBar makes it easy to attach a projector to a tree or vertical circular support with a diameter of 150 to 250 mm.

Thanks to two straps and two ratchet hooks, you can position a device in just a few minutes in places that are usually difficult to access.



Features


- Support for outdoor projectors for posts and trees with a diameter of 150 to 250 mm
- 47 cm horizontal bar (Ø 48 mm)
- Black powder-coated steel
- Ideal for temporary installations
- Do not use with loads exceeding 50 kg
- The maximum working load depends on the type of mounting
- Always check that the post or tree is suitable for the load
- Always use safety slings when mounting at height, both for the support itself and for the item to be suspended
- Weight 2.29 kg
- Supplied with two hanging straps

SUP-TreeBar

Projector mount for attachment to poles or trees, with 47 cm horizontal bar (Ø 48 mm)


Attaching the straps

- Thread the two ratchet straps onto the bracket for posts and trees.
- Ensure that the straps are not twisted.
- Place the pole and tree mount against a tree or vertical structure.
- Thread the ratchets.
- Tighten the ratchets until the clamp is secure.
- Ensure that the support remains in position.
- Mount an outdoor projector on the bracket using a hook or clamp.
- Install a safety hook using a sling suitable for the weight of the projector.



Using the ratchet hook

- While the second person holds the bracket, pass the strap through as shown in Figure 1.
- Operate the hook lever as shown in figure 2 until the necessary tension is achieved to hold the bracket securely in place.





SUP-TreeBar - H11812

Version 1 - 10-2025

Finalising the installation

- The figure below shows the SUP-TreeBar correctly installed.
- Do not forget to secure the projector with a safety sling.



The weight of the attached device must not exceed 50 kg.

Caution:

Ensure that the post or tree is strong enough to safely support the weight of the bracket and its projector.

Also ensure that the assembly cannot slip out of its bracket. The straps must be replaced if they are damaged.

These supports are designed for temporary installation during events and must not remain in place permanently.

The SUP-TreeBar must be installed by two people.

The installation area for the SUP-TreeBar must be secure. Ensure that no one is standing underneath it during installation.

Manufactured in the EU
Distributed by HITMUSIC S.A.S
595 Rue de la Pièce Grande
46230 FONTANES
www.hitmusic.eu